

Blueskin[®] Adhesive

Blueskin[®] Spray-Prep

Adhesives for Self-Adhered Membranes

Physical Properties

	<u>Blueskin[®] Adhesive</u>	<u>Blueskin[®] Spray-Prep</u>		
-Colour	Blue	Clear amber	-Service Temp	Minus 40°C to 70°C
-Solids by Weight	35%		-Application Temp	Minus 12°C to 40°C
-Weight	0.8 kg/l (6 lbs./gal. U.S.)		-Flammability	
	(approx.)	3 to 5 m ² /can	Wet	Flammable
-Coverage	2 to 6 m ² /l (up to 250 ft ² /gal. U.S.) depending on porosity and texture of surface.	(30 to 50 ft ² /can)	Dry	Burns
-Drying Time		3 minutes		
Initial Set	30 minutes	20 minutes		
Set Through	2 hours			

Description

Blueskin[®] Adhesive is a rubber based adhesive for self-adhered membranes.

Features

- Quick setting
- Aggressive tack provides increased adhesion of membrane
- Suitable for application at normal and low temperatures
- Easily applied

Uses

Used as an adhesive to increase bond strength of self-adhered membranes such as **Blueskin[®] SA, Blueskin[®] WP 200, Blueskin[®] ROOF RF 200, Blueskin PE200HT, Vapor Bloc SA** or *modified***PLUS[®] SA** when applied to masonry, concrete, wood, gypsum board, DensGlass Gold[®] and metal surfaces.

Blueskin[®] Adhesive is the product of choice on above grade applications of self-adhered membranes where a quick setting, aggressive tack, solvent based adhesive is required.

Blueskin[®] Spray-Prep is ideal where a very fast drying adhesive is required. Convenient spray can application eliminates the need for brushes or rollers. Three minute tack time.

Designed for applications above -12°C.

Limitations

Solvent in product attacks polystyrene insulation. Avoid use where solvent odours may taint food or other susceptible products..

Packaging

Blueskin[®] Adhesive is packaged in 17L and 3.5L pails.

Blueskin[®] Spray-Prep is packaged in 425g spray cans.

Blueskin® Adhesive and Blueskin® Spray-Prep for Self-Adhered Membranes

Preparation

Surfaces must be dry and free from dust, dirt, grease, oil or other foreign matter.

Application

Blueskin® Adhesive: Apply by brush, roller or spray. Rollers should have a heavy nap of natural material such as lamb's wool. Allow Adhesive to dry for 30 minutes before applying membrane.

Blueskin® Spray-Prep: Shake can and spray. Allow to tack up for three minutes before applying membrane.

Coated surfaces not covered by membrane during the working day must be re-coated.

Clean Up

Use mineral spirits.

Caution

Contains extremely flammable solvents. Take suitable fire precautions. Do not allow smoking or welding in working area. Keep away from open flame or spark. Use under well ventilated conditions. Avoid prolonged breathing of vapours and repeated contact with skin. Excessive inhalation of vapours can cause dizziness. (Use respirator approved for organic vapours). Keep containers covered when not in use. Harmful if swallowed.

<>